
Special Specification 5036

Move Cattle Guard



1. DESCRIPTION

Move an existing cattle guard to the location specified on the plans or as directed by the Engineer.

2. MATERIALS

Furnish materials in accordance with the following Item:

- Item 400, "Excavation and Backfill for Structures."
-

3. CONSTRUCTION

3.1. **General.** Remove and salvage the existing cattle guard and concrete cattle guard supports. Move and install the salvaged cattle guard and concrete supports at the location indicated on the plans or as directed by the Engineer. Backfill the existing and proposed cattle guard locations with a material as shown on the plans or as directed by the Engineer.

3.2. **Installation.** Install cattle guard in accordance with the details shown on the plans, and the following item:

- Item 400, "Excavation and Backfill for Structures."

4. MEASUREMENT

This Item will be measured by each cattle guard moved.

5. PAYMENT

The work performed and materials furnished in accordance with this Item and measured as provided under "Measurement" will be paid for at the unit bid price for "Move Cattle Guard." The price is full compensation for excavation and backfill (including cement stabilized backfill); removing, moving, and installing the existing cattle guard and concrete supports; repairing or replacing cattle guard elements to the satisfaction of the Engineer if they are damaged during relocation; and for all labor, tools, equipment, and incidentals.