Test Procedure for

SAMPLING FLEXIBLE DELINEATOR AND OBJECT MARKER POSTS

Texas Department of Transportation

TxDOT Designation: Tex-737-I

Effective Dates: October 2007–February 2008.

ARCHIVE

1. SCOPE

1.1 This test method outlines the procedure for taking samples of flexible delineator and object marker posts.

1.2 The values given in parentheses (if provided) are not standard and may not be exact mathematical conversions. Use each system of units separately. Combining values from the two systems may result in nonconformance with the standard.

2. SAMPLING

2.1 Have an authorized representative of the Department select samples.

2.2 Take samples at the jobsite or at an approved Department stocking location prior to shipment to the jobsite.

3. PROCEDURES

3.1 Select a sample consisting of a minimum of three flexible posts from each lot or shipment of a particular type or size.

3.2 Select samples, at random, that represent of materials supplied.

Note 1—Samples will not be required when project quantities of a particular type or size of flexible post consist of 25 units or less. The engineer visually inspects these posts and reviews the certificate of compliance furnished by the manufacturer.

4. TAGGING/LABELING, DOCUMENTING, AND SHIPPING

4.1 Follow the procedures as detailed in Test Method Tex-701-I.

4.2 Tag or mark each sample, in a non-destructive manner, with the name of the flexible post, manufacturer's name, and quantity represented by the sample.

4.3 Complete Form 202 with all information pertinent to samples.

4.4 Wrap bundle to prevent damage in transit.

5. ARCHIVED VERSIONS

5.1 Archived versions are available.

ARCHIVE